

AREBOS

Dutch OvEn Accessories

AR-HE-LSGS012



Follow all safety precautions in this user manual to ensure safe use.

Thank you for your trust in AREBOS.

Table of contents

1. Introduction and safety instructions	3
1.1 Introduction	3
1.2 Explanation of symbols and residual hazards.....	3
1.3. Safety	4
General Safety Instructions	4
Risk of burns.....	4
Danger to children and pets.....	4
2. Scope of delivery and information	5
3. Assembly and commissioning.....	5
4. Storage and cleaning	6
5. Quality Notice	6
6. Environmentally friendly disposal	7
6.1 Disposal and packaging	7
6.2 Disposal of old equipment.....	7
EU Declaration of Conformity	8


Thank you for purchasing our product. Please read the instruction manual carefully before using the product for the first time. If you leave the product to third parties, these operating instructions must also be handed over. Keep the instruction manual for future reference. The drawings in this manual may not match the physical objects. Please refer to the physical objects.


1.Introduction and safety instructions

1.1 Introduction

- This instruction manual is intended to familiarize you with the installation, use and maintenance of the product. To install the device safely and correctly, please read the instruction manual **before** starting.


1.2 Explanation of symbols and residual hazards

 **WARNING!** This signal symbol/word refers to a hazard with a medium degree of risk which, if not avoided, can result in death or serious injury.


 **CAUTION!** This signal symbol/word refers to a hazard with a low degree of risk which, if not avoided, can result in a minor or moderate injury.

Hint! This signal symbol/word warns of possible property damage.




 **WARNING!** Read the safety rules and instructions carefully. Failure to comply with safety warnings and instructions may result in electric shock, fire and/or serious injury. **Keep all safety warnings and instructions for future reference.**



 **WARNING!** in front of a hot surface!
The pots get very hot on all components during use. Lift the lid exclusively with heat-resistant gloves or a special lid lifter. Never touch or carry the pot without heat protection while in use. Do not quench or drop with cold water.



 **WARNING!** The pots should not be covered to avoid overheating and the risk of fire!
The symbol indicates that it is not permitted to hang objects (e.g. towels, clothes, etc.) above thepots or directly in front of them.



Follow the instructions
Notices with this symbol indicate that

that the operating instructions must be followed.



This product must not be disposed of with household waste!

1.3. Safety

General Safety Instructions

- The pot may only be used for the preparation of grillable food. All requirements of these instructions must be complied with.
- The pot must be placed on a safe, horizontal and heat-resistant surface before use. Remove the device from the packaging!
- The pot must be used far away from flammable or delicate materials.
- Do not make any changes to the product.
- Damaged parts or accessories may no longer be used.
- The manufacturer cannot be held liable for any damage caused by improper, reckless or improper use.
- The manufacturer assumes no responsibility for damage that occurs during the use of the device or for complaints from third parties.
- Never transport the pot during operation.
- Wear heat-resistant gloves when preparing.
- Keep electrical wires away from hot surfaces of the pot .
- For private use only!

Risk of burns

- **Caution!** This pot gets very hot and must NOT be moved during operation.
- Use only outdoors in a well-ventilated area! When used indoors, harmful gases are produced that can be potentially fatal. Never use the Dutch Oven under flammable roofs, shelters, etc.
- Wait for the pot to cool down before transporting or cleaning it.

Danger to children and pets

- **Caution!** Keep children and pets away from the pot!
- Stay alert.
- Never leave the hot pot unattended.

2. Scope of delivery and information

Scope of delivery

- 1 x Dutch oven pot with lid / 1 x frying pan / 1 x holder / 1 x storage bag / 2 x protective gloves / 1 x stainless steel cleaning brush



Device information

The Dutch oven has its origins in the "Wild West" and was used as a universal cooking utensil. Due to its very flexible application possibilities, it is still considered one of the most popular grilling tools among outdoor fans and barbecue enthusiasts.


The thick-walled pot made of high-quality cast iron has excellent thermal conductivity, as well as heat retention, making it ideal for cooking, baking and braising. Best results with stews, goulash, soups, roasts or even breads and cakes are guaranteed!

3. Assembly and commissioning

Initial commissioning

- Remove the product and all accessories from the packaging. Check that there are no signs of damage to the product.
- Remove the packaging completely.
- Clean the pots with hot water, please do not use washing-up liquid or other cleaners under any circumstances, as this may damage the protective layer and the pot would rust.
- Dry the cast iron pot completely.
- We recommend that you first bake in before using it for the first time in order to create a thicker protective layer as a basis for permanent use.

Burn-in process

- To protect your cast iron pot from rust, you need to bake it in. You can do this before the first use or between uses if the patina (protective layer) is damaged or rust has formed.
- If there are rust stains on the pot, they should first be removed with a wire brush. Then the pot must be thoroughly cleaned with warm water and dried well.
- After thoroughly cleaning your pot, you can rub it either with a special nourishing paste inside and out, or with neutral oil or vegetable fat. To do this, use sunflower oil, coconut oil or other fats resistant to high temperatures.
- After that, the pot is placed in the oven for two hours at about 180 degrees Celsius or burned on the grill.
-  Attention! When this product burns, there may be increased smoke development. We recommend that you burn in the open air!
- Allow the Dutch Oven to cool slowly and grease all parts again. The Dutch Oven is now ready for use.


4. Storage and cleaning

- The pots are made of cast iron, which is susceptible to rust. Therefore, they must be thoroughly cleaned and maintained after each use to ensure a long service life.
- After boiling, let the pots cool and remove any food debris. If necessary, you can use a sponge or brush to remove glued or burned-in debris.
- Of course, the pots are not suitable for the dishwasher.
- After cleaning, the pots must always be thoroughly dried and rubbed with oil or vegetable fat. It is best to rub with a thin, lint-free cloth.
- The pot should be stored in a dry place and allowed to breathe. For better ventilation of the pot, place a cardboard or wooden wedge between the lid and the pot.

5. Quality Notice

- Minor unevenness in the surface or small unevenness in the wall thickness is normal and not a reason for complaint.
- A slight "tilting" of the lid cannot be ruled out 100%, here the production-related tolerance range is 2mm. A lid that is not 100% on does not pose any problems during use and does not affect the function.

6. Environmentally friendly disposal

 **Warning! from the risk of suffocation!** Packaging material is dangerous for children. Never let children play with packaging material.

6.1 Disposal and packaging

- The packaging of your device is made of materials that are necessary to guarantee effective protection during transport. These materials are fully recyclable, thus reducing the environmental impact. Dispose of the packaging in a bin for recyclable materials.

6.2 Disposal of old equipment

- Old appliances must be disposed of in accordance with the guidelines and regulations of local waste disposal. Contact your local administration about the address of the nearest recycling center and deliver your device there.



The symbol of the crossed-out rubbish bin on an old electrical or electronic appliance means that it must not be disposed of with household waste at the end of its service life. Collection points for waste electrical and electronic equipment are available in your area for free return. You can obtain the addresses from your city or local government. You can www.arebos.de find out about other return options created by us on our website.



The separate collection of waste electrical and electronic equipment is intended to enable the reuse, recycling or other forms of recovery of waste and to avoid the negative consequences of disposal on the environment and human health.

Note on battery disposal

The symbol of the crossed-out dustbin on batteries or accumulators means that they must not be disposed of with household waste at the end of their service life. If batteries or accumulators contain mercury (Hg), cadmium (Cd) or lead (Pb), you will find the respective chemical symbol below the symbol of the crossed-out trash can. You are legally obliged to return old batteries and accumulators after use. You can do this free of charge at the retail store or at another collection point near you. Addresses of suitable collection points can be obtained from your city or local government.

Our customer service number: Tel. +49 (0) 931 9080 3000

Fax: +49 (0) 931 4523 2799 / E-Mail: info@arebos.de

Office address: Canbolat Vertriebs GmbH • Gneisenastraße 10-11 • 97074 Würzburg

The return address can be found in the imprint: <https://www.arebos.de/impressum/>

Sales tax identification number: DE 263752326

The court of entry in the commercial register is Würzburg, HRB 10082

WEEE Reg. No. DE 61617071

EU Declaration of Conformity

We, the

Canbolat Vertriebsgesellschaft mbH
Gneisenaustraße 10-11
97074 Würzburg, Germany

declare under the sole responsibility that the following product:

Brand

AREBOS

Product

Dutch Oven Accessories

Product model

AR-HE-LSGS012

Article

4252023111355

The subject matter of the declaration described above is in accordance with the relevant harmonization legislation of the European Union.

Place and date of exhibition:

Würzburg, 25.05.2023

Signature:



Dipl.-Inform. (Univ.) Korhan Canbolat, Managing Director

If the device is modified without our consent, this declaration of conformity loses its validity.