

AREBOS

Swivel grill

AR-HE-SG



Follow all safety precautions in this user manual to ensure safe use.

Thank you for your trust in AREBOS.

Table of contents

1. Introduction and safety instructions	3
1.1 Introduction	3
1.2 Explanation of symbols and residual hazards	3
1.3. Safety	4
General Safety Instructions	4
2. Scope of delivery	5
3. Assembly	6
4. Storage and cleaning	6
5. Environmentally friendly disposal	7
5.1 Disposal and packaging	7
5.2 Disposal of old equipment	7
EU Declaration of Conformity	8

Thank you for purchasing our product. Please read the instruction manual carefully before using the product for the first time. If you leave the product to third parties, these operating instructions must also be handed over. Keep the instruction manual for future reference. The drawings in this manual may not match the physical objects. Please refer to the physical objects.

1. Introduction and safety instructions

1.1 Introduction

- This instruction manual is intended to familiarize you with the installation, use and maintenance of the product. To install the device safely and correctly, please read the instruction manual **before** starting.

1.2 Explanation of symbols and residual hazards

 **WARNING!** This signal symbol/word refers to a hazard with a medium degree of risk which, if not avoided, can result in death or serious injury.

 **CAUTION!** This signal symbol/word refers to a hazard with a low degree of risk which, if not avoided, can result in a minor or moderate injury.

Hint! This signal symbol/word warns of possible property damage.



 **WARNING!** Read the safety rules and instructions carefully. Failure to comply with safety warnings and instructions may result in electric shock, fire and/or serious injury. **Keep all safety warnings and instructions for future reference.**



 **WARNING!** in front of a hot surface!
The pots get very hot on all components during use. Lift the lid exclusively with heat-resistant gloves or a special lid lifter. Never touch or carry the pot without heat protection while in use. Do not quench or drop with cold water.



 **WARNING!** The pots should not be covered to avoid overheating and the risk of fire!
The symbol indicates that it is not permitted to hang objects (e.g. towels, clothes, etc.) above the pots or directly in front of them.



Follow the instructions
Notices with this symbol indicate that the operating instructions must be followed.



This product must not be disposed of with household waste!


1.3. Safety

General Safety Instructions

- The barbecue may only be used outdoors.
- Always place the grill on a flat surface, away from flammable materials and in a windless environment.
- Keep children and animals away. Do not leave the grill unattended.
- Attention: fire hazard!
- The grill must be heated for at least 30 minutes before using it.
- The maximum amount of coal that can be used is 1.7 kg
- Here's how to fire up the grill properly:
 - Place 3-4 lighters in the fire bowl and light them with a long lighter
 - Place the coal around the burning lighters. Now build up the coal like a pyramid.
 - The coal should now start to burn, bring it to glow so that the desired temperature can be reached
- Before grilling, wait for the coal to form a light layer of ash
- Warning: the grill gets very hot!
- Use grill gloves and grill tongs. Do not touch the metal parts with your bare hands.
- Warning: do not use alcohol or gasoline for lighting.
- Do not move the swivel grill off the pitch if it is still hot or burning
- Do not clean the grill until it has cooled down completely
- Never dispose of hot ash in the trash. Please wait until it has cooled down completely (at least 24 hours).

Attention: The metal parts of the grill can discolor due to the intense heat. This is not a reason for complaint/defect but a natural reaction of the material.

2. Scope of delivery



Number/Letter	Designation	Quantity
1	Top lid	1
2	Poppet head	1
3	Chain	1
4	Bracket-top	3
5	Bracket-middle	3
6	Bracket-bottom	3
7	Bracket-leg	3
8	Grill	1
9	Fire Bowl	1
10	Legs	3
11	Support	1
A	Screws M6x35	6 sets
B	Screws M5x35	3 sets
C	Screws M6x10	1 set

3. Assembly

Check all parts for completeness and damage before starting assembly. Read the instructions carefully.

In the event of non-compliance with the instructions or self-inflicted damage, the seller is not liable.

1. Connect parts 4, 5, 6, and then 1
2. Connect Part 7 to the finished part from Step 1 to Part B
3. Connect Part 11 to Part 10 with the help of Part A
4. Connect Part 2 at the bottom of Part 1 with the help of Part C
5. During the grilling process, place the lower end of part 3 on the hoe which is located at part 8, then through part 2 to hang it. Adjust the height of Part 8 with the help of Part 2

The dismantling works in the same way only backwards.

4. Storage and cleaning

- Clean the grill thoroughly after each use to ensure a long service life.
- Allow the grill to cool down after grilling and remove any food debris. If necessary, you can use a sponge or brush to remove glued or burned-in debris.
- Of course, the individual parts are not suitable for the dishwasher.
- The swivel grill should be stored in a dry and windless place.

5. Environmentally friendly disposal

 **Warning! from the risk of suffocation!** Packaging material is dangerous for children. Never let children play with packaging material.

5.1 Disposal and packaging

- The packaging of your device is made of materials that are necessary to guarantee effective protection during transport. These materials are fully recyclable, thus reducing the environmental impact. Dispose of the packaging in a bin for recyclable materials.

5.2 Disposal of old equipment

- Old appliances must be disposed of in accordance with the guidelines and regulations of local waste disposal. Contact your local administration about the address of the nearest recycling center and deliver your device there.



The symbol of the crossed-out rubbish bin on an old electrical or electronic appliance means that it must not be disposed of with household waste at the end of its service life. Collection points for waste electrical and electronic equipment are available in your area for free return. You can obtain the addresses from your city or local government. You can www.arebos.de find out about other return options created by us on our website.



The separate collection of waste electrical and electronic equipment is intended to enable the reuse, recycling or other forms of recovery of waste and to avoid the negative consequences of disposal on the environment and human health.

Note on battery disposal

The symbol of the crossed-out dustbin on batteries or accumulators means that they must not be disposed of with household waste at the end of their service life. If batteries or accumulators contain mercury (Hg), cadmium (Cd) or lead (Pb), you will find the respective chemical symbol below the symbol of the crossed-out trash can. You are legally obliged to return old batteries and accumulators after use. You can do this free of charge at the retail store or at another collection point near you. Addresses of suitable collection points can be obtained from your city or local government.

Our customer service number: Tel. +49 (0) 931 9080 3000

Fax: +49 (0) 931 4523 2799 / E-Mail: info@arebos.de

Office address: Canbolat Vertriebs GmbH • Gneisenaustraße 10-11 • 97074 Würzburg

The return address can be found in the imprint: <https://www.arebos.de/impressum/>

Sales tax identification number: DE 263752326

The court of entry in the commercial register is Würzburg, HRB 10082

WEEE Reg. No. DE 61617071

EU Declaration of Conformity

We, the

Canbolat Vertriebsgesellschaft mbH
Gneisenaustraße 10-11
97074 Würzburg, Germany

declare under the sole responsibility that the following product:

Brand

AREBOS

Product

Swivel grill

Product model

AR-HE-SG

Article

4252023111379

The subject matter of the declaration described above is in accordance with the relevant harmonization legislation of the European Union.

Place and date of exhibition:

Würzburg, 25.05.2023

Signature:



Dipl.-Inform. (Univ.) Korhan Canbolat, Managing Director

If the device is modified without our consent, this declaration of conformity loses its validity.