


AREBOS

Wall shelf with 30 stacking boxes

AR-HE-WR30S



Please follow all security measures in this user's manual to ensure a secure use.

Thank you for trusting in AREBOS.

Table of Contents

1. Safety Instructions.....	3
1.1 Explanation of the symbols.....	3
1.2 Safety warnings.....	3
2. Installation	3
3. Cleaning and Maintenance	4
4. Disposal instruction	5
4.1 Disposal of the packaging	5
4.2 Disposal of waste equipment	5
4.3 Meaning of the “dustbin”	5
Imprint.....	6

Please read and save these instructions. Read through this user's manual carefully before using this product. Protect yourself and others by observing all safety information, warnings and cautions. Failure to comply with instructions could result in personal injury and/or damage to product or property. Please retain instructions for future reference.

1. Safety Instructions

1.1 Explanation of the symbols



Warning! Read the safety instructions carefully. Failure to follow the safety precautions could result in serious injury or damage. Keep the operating instructions in a safe place.

1.2 Safety warnings

Precautions during installation:

1. Install only according to these instructions. Improper installation can cause hazards.
2. Wear protective goggles and heavy-duty work gloves during installation.
3. Keep the installation area clean and well lit.
4. Keep away from other people during the installation.
5. Do not install if you are under the influence of medication or drugs or if you are tired.

Precautionary measures for use:

1. This product is not a toy. Do not allow children to play with or near the product.
2. Use the product only for its intended purpose.
3. Check the product before use. Do not use the product if any parts are loose or damaged.

2. Installation

Read all safety installations before installing and using this product.

1. Install the product on a solid wooden base that can support the weight when the boxes are fully loaded. Carefully check the mounting surface to ensure that there are no hidden electrical wires, cables or pipes.
2. Point the slots of the perforated panels (part 3) upwards so that the slots holding the boxes are open at the top.
3. Hold the perforated panels (part 3) against the surface on which they are to be mounted and align them using a spirit level (not included in the delivery). Now set the mark for the 8 mounting holes.
4. After checking the mounting surface for hidden wiring, drill the 8 fixing holes to use 3 mm wood screws. These screws must be at least 50 mm long.
5. Mount the perforated panels (part 3) on the wood surface using 8 wood screws (not included). All 8 wood screws must be screwed firmly into the wood panel.
6. Hang the boxes into the perforated boards by inserting the rear lip of the boxes into the open slot of the perforated board. Hang the smaller boxes (part 1) in the top 3 rows and the larger boxes (part

2) in the 2 bottom rows (see fig. 1).

3. Cleaning and Maintenance

1. Before each use check the condition of the boxes and the perforated panels (part 3) for cracks, breaks or other defective parts (see fig. 1). Make sure that the perforated boards have not come loose from the wooden board.
2. If necessary, clean the boxes with a damp cloth or rag.




Fig. 1

Parts number	Description	Quantity
1	Middle boxes	18
2	Big boxes	12
3	Black perforated panels	2

4. Disposal instruction

4.1 Disposal of the packaging

- Please make reference to the guidelines and standards for appropriate disposal of the packaging valid in your region. In part, the package may consist of plastic bags - watch this respect, with special care to ensure that this is not out of the reach of children. There is a risk of suffocation!

4.2 Disposal of waste equipment

- Equipment must be disposed of in accordance with the rules and regulations of the local waste disposal.
- At the end of the long life of your article, please dispose of the valuable raw materials for proper disposal so that proper recycling can take place. If you are not sure how to proceed, the local waste disposal companies or recycling centers are happy to help.

4.3 Meaning of the “dustbin”



Protect our environment; electrical appliances do not belong in household waste. Use the provided for the disposal of electrical equipment collection points and enter your electrical and electronic equipment that you no longer use. They help ensure that the potential effects of incorrect disposal on the environment and human health to be avoided. So, do your part to recycle, recycling and other forms of recovery of waste electrical and electronic equipment. Information on where the device is disposed of, please contact your local authorities or local Governments.

Our customer service number: +49 (0) 931-45232700

Imprint

Name of the product: Wall shelf with 30 stacking boxes
Model Nr.: AR-HE-WR30S
Art. Nr.: 4260627426043

If the product has any modification not allowed by us, this declaration loses its validity.

Date/Manufacturer Signature/Location:

Würzburg, 10 September 2020



Identification of the signatory:
Korhan Canbolat, head of the company

Authorised representative for the technical documentation:
Korhan Canbolat

Office address:
Canbolat Vertriebs GmbH
Gneisenaustraße 10-11
D-97074 Würzburg

Return address can be found in the imprint: <https://www.arebos.de/impressum/>

VAT identification number: DE 263752326
Court of the Commercial Register is Würzburg, HRB 10082
WEEE Reg.-No. DE 61617071