AREBOS

Ashes Vacuum Cleaner Eco

AR-HE-AS408



Please follow all security measures in this user's manual to ensure a secure use.



Thank you for trusting in AREBOS.

<u>User's Manual – AREBOS Ashes Vacuum Cleaner Eco</u>

Table of Contents

1. Safety Instructions	3
1.1 Explanation of the symbols	3
2. Appliance Figure	
3. Assembly	5
4. Operation	6
5. Cleaning and Maintenance	
6. Error Detection	
7. Technical Data	7
8. Disposal instruction	8
8.1 Disposal of the packaging	8 8
EU Declaration of Conformity	

Please read and save these instructions. Read through this user's manual carefully before using this product. Protect yourself and others by observing all safety information, warnings and cautions. Failure to comply with instructions could result in personal injury and/or damage to product or property. Please retain instructions for future reference.

1. Safety Instructions

1.1 Explanation of the symbols



This product **must not** be disposed of with household waste!



By means of a CE marking, it can be recognized that a product complies with the legal requirements of European legal standards and therefore may be traded within the European Community.



Protective insulated housing (protection class II)!



Restriction of the use of certain hazardous substances in the area of heavy metals, brominated flame retardants and plasticisers to protect human health and the environment



Warning of electrical voltage!



Warning! Read the safety instructions carefully. Failure to follow the safety precautions could result in serious injury or damage. Keep the operating instructions in a safe place.

1.2 Safety Warnings

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or a similarly qualified person in order to avoid a hazard.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

<u>User's Manual – AREBOS Ashes Vacuum Cleaner Eco</u>

The vacuum is specifically designed to remove warm (<60°C) or cold (not burning) ash.

0	Do not vacuum any sharp-edged, hot or incandescent materials.	
\bigcirc	The appliance should not be exposed to heat.	
\bigcirc	Do not vacuum any moist or liquid substances. Never immerse the appliance in water.	
\Diamond	Unplug the appliance form the mains supply socket after use and before every cleaning. Pull the plug, not the mains cable, in order to disconnect the appliance from the mains.	
\bigcirc	Do not put any object into openings. Do not use with any opening blocked. Keep free of dust, lint, hair etc.	
0	Do not use the vacuum cleaner without dust container or dust filter bag in place.	
0	Do not vacuum any flour, cement etc., in order to avoid the overloads.	
\Diamond	The appliance should only be cleaned with a dry or damp cloth; it should never be immersed into water. Do not use any solvents for cleaning.	
0	This appliance is intended for domestic use only and not for commercial applications.	
0	Avoid the nozzle or brush touching the surface of the furniture.	
0	Do not use the mains wire to carry the appliance. Do not pull the mains wire over sharp edges.	8

2. Appliance Figure



3. Assembly


HEPA Filter: Inspect the HEPA filter in the dust container.	V type nut
Dust container:	
Attach the dust container to the hand vacuum cleaner.	V
Flexible hose:	
To use the flexible hose, insert the end of the hose into the suction hole.	L
Make sure, that it is snapped in the position.	
Accessories:	
Choose your desired accessory and attach it to the suction hole.	

4. Operation

Before you start the appliance, make sure that the dust filter is in the position.
Unwind the power cord.
Plug the appliance and switch on.
Unplug the appliance after use.

5. Cleaning and Maintenance

V type nut	Open the dust container.
Metal rod Dust filter Cover	Take out the HEPA filter.
	Empty the dust container.
	Wash off the HEPA filter with water.



6. Error Detection

Before you contact our service center, please check the following:


Problem	Possible reason	Advice
Motor does not start	-Power cord not firmly plugged	-Plug unit firmly
	into outlet	-Check the Outlet
	-Outlet damaged	-Switch on the appliance
	-Cleaner not switched on	
Suction power is weaker	-Unit clogged	-Remove the blockage
	-HEPA filter needs cleaning	-Clean the dust filter
	-Dust container not in position	-Attach the dust container again to
	-Filter blocked	the cleaner
		-Clean the filter

7. Technical Data

Rated voltage: 220-240V ACRated frequency: 50/60Hz

• Power: 1000W

Operating pressure: ≥ 16 kPa
 Sound level: <84dB(A)
 Operating radius: 1.5m
 Circuit illustration:



8. Disposal instruction

8.1 Disposal of the packaging

 Please make reference to the guidelines and standards for appropriate disposal of the packaging valid in your region. In part, the package may consist of plastic bags - watch this respect, with special care to ensure that this is not out of the reach of children. There is a risk of suffocation!

8.2 Disposal of waste equipment

- Equipment must be disposed of in accordance with the rules and regulations of the local waste disposal.
- At the end of the long life of your article, please dispose of the valuable raw materials for proper disposal so that proper recycling can take place. If you are not sure how to proceed, the local waste disposal companies or recycling centers are happy to help.

8.3 Meaning of the "dustbin"



Protect our environment; electrical appliances do not belong in household waste. Use the provided for the disposal of electrical equipment collection points and enter your electrical and electronic equipment that you no longer use. They help ensure that the potential effects of incorrect disposal on the environment and human health to be avoided. So, do your part to recycle, recycling and other forms of recovery of waste electrical and electronic equipment. Information on where the device is disposed of, please contact your local authorities or local Governments.

Our customer service number: +49 (0) 931-45232700

Canbolat Vertriebs GmbH • Gneisenaustraße 10-11 •97074 Würzburg

EU Declaration of Conformity

We,

Canbolat Vertriebs GmbH, Gneisenaustraße 10-11, 97074 Würzburg, Germany,

Hereby declare that the product named below, seen its design and construction as well as according to our sales, has been complied with the relevant and basic health and safety EU-requirements.

Name of the product: Ashes Vacuum Cleaner Eco

Art. Nr.: 4260627424955 Model Nr.: AR-HE-AS408

If the product has any modification not allowed by us, this declaration loses its validity.

Tested acc. to:

LVD 2014/35/EU

EMC 2014/30/EU

AfPS GS 2019:01 PAK

RoHS 2011/65/EU

EU Standard:

EN 60335-2-2:2010+A11:2012+A1:2013

EN 60335-1:2012+AC :14+A11 :14+A13 :2017+A1 :2019+A2 :2019+A14 :2019

EN 62233: 2008

EN 55014-1:2017

EN 55014-2:2015

EN 61000-3-2:2014

EN 61000-3-3:2013

Date/Manufacturer Signature/Location:

Würzburg, July 28, 2020

Identification of the signatory:

Korhan Canbolat, head of the company

Authorised representative for the technical documentation:

Korhan Canbolat

Office address:

Canbolat Vertriebs GmbH Gneisenaustraße 10-11 D-97074 Würzburg

Return address can be found in the imprint: https://www.arebos.de/impressum/

VAT identification number: DE 263752326

User's Manual – AREBOS Ashes Vacuum Cleaner Eco
Court of the Commercial Register is Würzburg, HRB 10082 WEEE RegNo. DE 61617071
10
10