

Follow all safety precautions in this user manual to ensure safe use.

Thank you for trusting AREBOS.

-

## Table of contents

1 Introduction and safety instructions	3
1.1 Introduction	3
1.2 Explanation of symbols	
1.3 Important safety instructions	5
1.4 Intended use	7
2 Scope of delivery	8
3 Use	
4 Cleaning	
5 Storage	10
6 Specifications	10
7 Environmentally friendly disposal	11
7.1 Disposal and packaging	11
7.2 Disposal of waste equipment	11
EU Declaration of Conformity	12

Thank you for purchasing our product. Please read the instruction manual carefully before using the product for the first time. If you leave the product to third parties, this operating manual must also be handed over. Keep the instruction manual for later reference. The drawings in this guide may not match the physical objects. Please refer to the physical objects.

### 1 Introduction and safety instructions

### **1.1 Introduction**

• This guide is intended to familiarize you with the installation, use, and maintenance of the product. To install the device safely and correctly, please read the user manual **before** you begin.

### 1.2 Explanation of symbols



**WARNING!** Read the safety instructions carefully. Failure to comply with safety precautions can lead to serious injury or damage. Keep the instruction manual in a safe place.

WARNING! from electrical voltage!



Be careful when using this article!



Read the instructions for use



Do not pierce with needles



Do not be folded or torn



Not suitable for infants (0-3 years)

#### Original User Manual – AREBOS Heated jacket / vest



Machine wash at 30°C



Do not bleach



Drum drying at low temperature



Do not iron



Do not dry clean



Do not wring



Wash



This product **must not** be disposed of with household waste!

On the basis of a CE marking, it can be recognized that a product complies with the legal provisions of European legal standards and may therefore be traded within the European Community.

#### **1.3 Important safety instructions**

- Your safety is most important to us. So please make sure you read the user manual before installing and using the product. If you are unsure about any information in this manual, please contact the dealer from whom you purchased the device.
- **WARNING!** Read all safety and use instructions. Failure to follow the safety instructions and instructions may cause electric shock, fire and/or serious injury. Keep all safety and use instructions for the future.
- DO NOT use the product if you have not yet read the instruction manual.
- Make sure you have read the user manual thoroughly and understood the contents before you begin the installation.
- The instructions are in the interest of your safety.
- **WARNING! Suffocation!** Packaging material is dangerous for children. Never let children play with packaging material.
- This garment is not intended for use by children and persons with limited physical, sensory or mental abilities or lack of experience and knowledge.
- This garment may be used by children aged 8 and over and persons with limited physical, sensory or mental abilities or lack of experience and knowledge if they are supervised by or instructed by a person responsible for their safety in the safe handling of the garment and understand the dangers involved. Otherwise, there is a risk of incorrect operation and injuries.
- **Supervise children.** This ensures that children do not play with the garment.
- Cleaning and maintenance of the garment by children must not be carried out without supervision.
- If you notice that you experience the following symptoms while using the garment, take off the garment immediately and consult a doctor. Otherwise, there is a risk of heat exhaustion or heat stroke.

**First signs:** any discomfort; excessive sweating; neck pain; nausea; Dizziness or drowsiness **possible symptoms of heat exhaustion/heat stroke:** nausea and vomiting; throbbing headaches; dizziness and drowsiness; Absence of sweat secretion; red, hot and dry skin; muscle weakness or seizures; palpitations; rapid, shallow breathing; behavioral changes such as confusion, disorientation or tumbling gait; Unconsciousness.

- Do not use the garment if you suffer from discomfort that makes you sensitive to overheating or if you have a body aid. Check with your doctor and/or body aid manufacturer to see if you can use this heated garment.
- **Turn off the heating of the garment when moving in a warm environment.** There is a risk of heat stroke.

- Do not use the garment to keep warm toddlers, helpless, sleeping or unconscious people, or people with circulatory disorders. The wearer must immediately perceive the temperature of the garment and his own well-being in order to avoid overheating.
- The garment is not intended for use in hospitals.
- **Do not put needles or other pointed objects in the garment.** A damaged heating element or a damaged cable of the connector causes a malfunction of the garment and increases the risk of electric shock or fire.
- Do not misuse the cable of the connector for external purposes such as wearing or pulling the garment or unplugging the power bank. Keep the cable away from oil, sharp objects or moving parts. Do not bend the cable. A damaged heating element or a damaged cable of the connector causes a malfunction of the garment and increases the risk of electric shock or fire.
- **The garment is not waterproof.** Penetrating water increases the risk of electric shock. Should the garment still get wet, immediately unplug the power bank and remove it from the power bank adapter.
- **Do not fold a heated garment or store items on it.** A damaged heating element or a damaged cable of the connector causes a malfunction of the garment and increases the risk of electric shock or fire.
- Pay careful attention to the care and cleaning instructions of the garment. In the absence of care, there is a risk of electric shock or fire.
- Allow the garment to cool completely before storing it.
- Check at regular intervals to see if the garment is showing signs of wear or damage. If such signs are present or if the garment has been improperly used, do not continue to use the garment and return it to the retailer.
- Have your garment repaired only by qualified specialist personnel and only with original spare parts. This ensures that the safety of the garment is maintained.
- **Do not modify the heated workwear.** The heating elements must not be moved.
- Do not open the power bank. There is a risk of a short circuit.
- In case of damage and improper use of the power bank, vapours may escape. The power bank may burn or explode. Supply fresh air and consult a doctor if you have any complaints. The fumes can irritate the respiratory tract.
- If used incorrectly or if the power bank is damaged, flammable liquid may leak out of the power bank. Avoid contact with it. In case of accidental contact with water, rinse. If the liquid gets into the eyes, seek additional medical help. Leaking power bank fluid can cause skin irritation or burns.
- The power bank can be damaged by pointed objects such as nails or screwdrivers or by external force. There may be an internal short circuit and the power bank may burn, smoke, explode or overheat.
- Keep the unused power bank away from paper clips, coins, keys, nails, screws or other small metal objects that could cause contacts to be bridged. A short circuit between the power bank contacts can cause burns or fire.
- Use the power bank only in products of the manufacturer. This is the only way to protect the power bank from dangerous overload.
- **Charge the power bank only with suitable chargers.** With a charger suitable for a particular type of power bank, there is a risk of fire when used with other power banks.



#### Protect the power bank from heat,

**e.g. also from constant sunlight, fire, dirt, water and moisture.** There is a risk of explosion and short circuits.

- Protect the garment from heat with the power bank plugged in, e.g. also from constant sunlight, fire, water and moisture. There is a risk of explosion.
- Use only the power bank recommended under "Specifications". When using other power banks, there is a risk of explosion.
- **Do not plug the power bank into the power bank adapter if the adapter is defective.** The power bank may fall out during operation.
- Observe the instructions for the disposal of the power bank.

#### Matters requiring attention:

- If you do not use the device for a long time, please do not connect it to the power bank.
- Do not use water with high temperature or highly acidic detergents.
- It is strictly forbidden to use electricity for wet clothes. Please turn off the power immediately if you get wet in the rain.
- The duration of continuous heating depends on the capacity of the power bank.

#### 1.4 Intended use

• The garment is designed to keep the body warm in cold ambient temperatures.

### 2 Scope of delivery

1x Heated jacket or vest / 1x power bank / 1x user manual



### 3 Use

- Remove the USB connector and connect it to the mobile power bank.
- Press the ON/OFF switch on the power bank.
- Press the temperature controller on the chest for 3 seconds to start the heater. When the red light is on, the automatic temperature control is heated.
- Manual setting for three levels of heating, the red light shows continuous high temperature heating, the white one shows continuous medium temperature heating, and the blue one shows continuous low temperature heating.
- Press the temperature control switch for 3 seconds and turn off the light to stop the heating.

### 4 Cleaning

#### Washing instructions:

• Take out the power bank and add a neutral detergent. Do not rub or beat them hard and use the washed clothes after natural ventilation and drying.



Machine wash at 30°C



Do not bleach



Drum drying at low temperature



Do not iron



Do not dry clean



Do not wring



Wash

### 5 Storage

Power bank

- If you do not use the device for a long time, please do not connect it to the power bank.
- Allow the garment to cool before folding and storing it.
- Store the garment in a dry, cool place.
- Do not place any other items on the garment.

### **6** Specifications

Heated Jacket / Heated Vest	with power bank	
Models	AR-HE-AT04* / AR-HE-HV0829* / AR-HE-WJ09*	
AR-HE-AT04S / 4252023108102 / AR-HE-AT04M - 4252023108263 / AR-HE-AT04L -		
4252023108270 / AR-HE-AT04XL - 4252023108287 / AR-HE-AT042XL – 4252023108294 //		
AR-HE-HV0829S - 4252023108232 / AR-HE-HV0829M – 4252023108348 / AR-HE-HV0829L –		
4252023108355 / AR-HE-HV0829XL – 4252023108362 / AR-HE-HV08292XL – 4252023108379 //		
AR-HE-WJ09S - 4252023108225 / AR-HE-WJ09M - 4252023108300 / AR-HE-WJ09L -		
4252023108317 / AR-HE-WJ09XL - 4252023108324 / AR-HE-WJ092XL - 4252023108331		
Sizes	S/M/L/XL/2XL	
Connection	Cable	
- Starting voltage	5.0 V (DC)	
- Output	2.1 A	

We reserve the right to make technical and visual changes to the article in the course of product improvements.

3.7 V / 10,000 mAh

### 7 Environmentally friendly disposal

**WARNING! Suffocation!** Packaging material is dangerous for children. Never let children play with packaging material.

#### 7.1 Disposal and packaging

• The packaging of your device is made of materials necessary to guarantee effective protection during transport. These materials are fully recyclable and thus reduce the environmental impact. Dispose of the packaging in a bin for recyclable materials.

#### 7.2 Disposal of waste equipment

• Waste equipment must be disposed of in accordance with the guidelines and regulations of local waste disposal. Contact your local administration via the address of the nearest recycling centre and deliver your device there.



Symbol of the crossed-out waste bin on an OLD electrical or electronic equipment indicates that it must not be disposed of in household waste at the end of its service life. Collection points for WASTE electrical and electronic equipment are available in your area for free returns. You can obtain the addresses from your city or local government. You can inform yourself on our website <u>www.arebos.de</u> about other return options created by us.

The separate collection of WEEE is intended to prevent reuse, recycling or other forms of recovery of WEEE, as well as the negative consequences of disposal on the environment and human health.

Our customer service number: Tel. +44 (0) 20 8068 5604 fax: +49 (0) 931 4523 2799 / e-mail: <u>info@arebos.de</u>

Office address: Canbolat Vertriebs GmbH • Gneisenaustraße 10-11 • 97074 Würzburg

Return address can be found in the imprint: https://www.arebos.de/impressum/

VAT identification number: DE 263752326 Registration court in the commercial register is Würzburg, HRB 10082 WEEE-Reg. No. DE 61617071

### **EU Declaration of Conformity**

# CE

We, the

**Canbolat Vertriebsgesellschaft mbH** Gneisenaustrasse 10-11 97074 Würzburg, Germany

declare, under sole responsibility, that the following product:

Brand	
-------	--

**AREBOS** 

Product

Heated jacket / vest

Product Model Article AR-HE-AT04\* / AR-HE-HV0829\* / AR-HE-WJ09\* AR-HE-AT04S / 4252023108102 / AR-HE-AT04M - 4252023108263 / AR-HE-AT04L - 4252023108270 / AR-HE-AT04XL - 4252023108287 / AR-HE-AT042XL - 4252023108294 // AR-HE-HV0829S -4252023108232 / AR-HE-HV0829M - 4252023108348 / AR-HE-HV0829L - 4252023108355 / AR-HE-HV0829XL - 4252023108362 / AR-HE-HV08292XL - 4252023108379 // AR-HE-WJ09S - 4252023108325 / AR-HE-WJ09M - 4252023108300 / AR-HE-WJ09L - 4252023108317 / AR-HE-WJ09XL - 4252023108324 / AR-HE-WJ092XL - 4252023108331 2014/30/EU 2011/65/EU/2015/863/EU

has been developed, designed and manufactured in accordance with the requirements of **European directives**:

The subject matter of the declaration described above is in accordance with the relevant harmonisation legislation of the European Union.

The evaluation is based on the	EN IEC 55014-1:2021
Subsequently applied harmonized	EN IEC 55014-2:2021
Standards:	IEC 62321-3-1:2013, IEC 62321-5:2013,
	IEC 62321-4:2013+AMD1:2017, IEC 62321-7-1:2015,
	IEC 62321-7-2:2017, IEC 62321-6:2015, IEC 62321-8:2017

Other applied technical standards and specifications:

Place and date of issue:

Würzburg, 24.08.2022

Signature:

Dipl.-Inform. (Univ.) Korhan Canbolat, Managing Director

If the device is modified without our consent, this declaration of conformity loses its validity.