

Convector 2000W

AR-HE MKV2000B



Follow all safety precautions in this user manual to ensure safe use.

CE

Thank you for your trust in AREBOS.

-

Table of Contents

1 Introduction and safety instructions	3
1.1 Introduction	
1.2 Symbol explanation and residual hazards	
1.3 Safety instructions	6
2 Scope of delivery and information	10
3 Installation and commissioning	11
4 Service	12
5 Errors and malfunctions	15
6 Maintenance and cleaning	17
7 Transport and storage	17
8 Specifications	18
9 Environmentally friendly disposal	20
9.1 Disposal and packaging	20
9.2 Disposal of waste equipment	20
EU Declaration of Conformity	21

Thank you for purchasing our product. Please read the instruction manual carefully before using the product for the first time. If you leave the product to third parties, this operating manual must also be handed over. Keep the instruction manual for later reference. The drawings in this guide may not match the physical objects. Please refer to the physical objects.

1 Introduction and safety instructions

1.1 Introduction

 This user manual is intended to familiarize you with the installation, use and maintenance of the product. To install the device safely and correctly, please read the user manual before you begin.

1.2 Symbol explanation and residual hazards

WARNING! This signal symbol/word refers to a hazard with a medium degree of risk which, if not avoided, may result in death or serious injury.

CAUTION! This signal symbol/word refers to a low-risk hazard which, if not avoided, may result in minor or moderate injury.

Hint! This signal symbol/word warns of possible property damage.







WARNING! Read the safety regulations and instructions carefully.

Failure to comply with safety instructions and instructions may cause electric shock, fire and/or serious injury. Keep all safety instructions and instructions for the future.



WARNING! from electrical voltage!

Remove the power plug from the power outlet before working on the device! Do not touch the power plug with damp or wet hands. Unplug the power cord from the power outlet by touching it on the power plug.

WARNING! from electrical voltage!


This symbol indicates that there are dangers to the life and health of persons due to electrical voltage.

Work on electrical components may only be carried out by an authorized specialist company!

WARNING! Danger of electric shock! The device must not come into contact with water, otherwise there is a risk of electric shock! Do not use this heater in wet rooms!







This symbol indicates that there are dangers to the life and health of individuals due to hot surfaces.

Parts of this device can get very hot and cause burns. Pay special attention when children or other vulnerable people are present!

This device can pose dangers if it is used improperly or not as intended by persons who have not been instructed! Note that the device is not a toy and does not belong in children's hands. Personnel qualifications!

Suffocation! Do not leave the packaging material carelessly. It could become a dangerous toy for children.

There is a risk of fire if installed improperly. Do not place the device on a flammable surface.

Do not place the device on high-pile carpets.

The device must not be covered to avoid overheating and fire hazard!

WARNING! The heater must not be covered to avoid overheating and fire hazard!

The symbol on the device indicates that it is not allowed to hang objects (e.g. towels, clothes, etc.) above the device or directly in front of it.

Follow the instructions Hints with this symbol indicate that that the operating instructions must be observed.

This product must not be disposed of with household waste!

On the basis of a CE marking, it can be recognized that a product complies with the legal provisions of European legal standards and may therefore be traded within the European Community.

This product has been tested and certified by Intertek. The symbol "GS" stands for tested safety. Products marked with this mark comply with the requirements of the German Product Safety Act (ProdSG).







CE



Behaviour in an emergency

- Turn off the device.
- In an emergency, disconnect the device from the power supply: Unplug the power cord from the power outlet by touching it on the power plug.
- Do not reconnect a defective device to the power connector.

Overheating protection

The device has a safety thermostat that is activated in case of overheating (exceeding the operating temperature) of the device.

- When the safety thermostat is turned on, the device turns off.
- When the device has cooled down sufficiently, the heating turns on again.
- Look for the cause of the overheating.

If the safety thermostat does not switch in case of overheating, the overheating protection triggers. The device then switches off completely. In this case, contact customer service to have the overheating fuse replaced.

1.3 Safety instructions

- Your safety is most important to us. So please make sure you read the user manual **before** installing and using the product. If you are unsure about any information in this manual, please contact the dealer from whom you purchased the device.
- DO **NOT** use the product if you have not yet read the instruction manual.
- Make sure you have read the user manual thoroughly and understood the contents before you begin the installation.
- The instructions are in the interest of your safety.

WARNING! This device may be used by children 8 years of age and older, as well as by persons with reduced physical, sensory or mental abilities or lack of experience and knowledge, if they have been supervised or instructed in the safe use of the device and understand the resulting dangers. Children are not allowed to play with the device. Cleaning and user maintenance must not be carried out by children without supervision.

WARNING! Children younger than 3 years of age should be kept away from the device unless they are constantly monitored. Children 3 years of age and younger than 8 years of age may only turn the device on and off if they are supervised or have been instructed in the safe use of the device and understand the resulting dangers, provided that:

that the device is placed or installed in its normal usage position.

Children from 3 years of age and younger than 8 years of age must not plug the plug into the socket, regulate the device, clean the device and/or perform maintenance by the user.

WARNING! Do not use the device in small rooms if there are people in it who can not leave the room on their own and are not under constant supervision.

- Do not operate the device in potentially explosive rooms or areas and do not place it there.
- Do not operate the device in an aggressive atmosphere.
- Place the device upright and stable on a load-bearing surface.
- Allow the device to dry after a wet cleaning. Do not operate it in the wet state.
- Do not operate or operate the device with damp or wet hands.
- Do not expose the device to a direct jet of water.
- Never insert objects or limbs into the device.
- Do not cover the device during operation.
- Do not remove any safety signs, stickers or labels from the device. Keep all safety signs, stickers and labels in a legible condition.
- Do not sit on the device.
- The device is not a toy. Keep children and animals away. Use the device only under supervision.
- Before each use, check the device, its accessories and connection parts for possible damage. Do not use defective devices or device parts.
- Make sure that all electrical cables outside the device are protected from damage (e.g. by animals). Never use the device in case of damage to electrical cables or the mains connection!
- The mains connection must comply with the specifications in the technical data.
- Plug the power plug into a properly secured power outlet.
- Select power cord extensions based on device power, cable length, and intended use. Fully unroll the extension cord. Avoid electrical overload.
- Before servicing, care or repairing the device, unplug the power cord from the power outlet by touching it on the power plug.
- Turn off the device and remove the power cord from the power outlet when not using the device.

- Never use the device if you notice damage to the power plug or power cord. If the power cord of this device is damaged, it must be replaced by the manufacturer or his customer service or a similarly qualified person to avoid hazards. Defective power cords pose a serious threat to health!
- During installation, observe the minimum distances to walls and objects as well as the storage and operating conditions according to the technical data (chapter Technical data).
- Do not use the device in the immediate vicinity of curtains, beds or sofas.
- Keep a safety distance of at least 1 m between the air inlet and the air outlet of the device and all flammable materials such as textiles, curtains, beds and sofas.
- Make sure the air inlet and air outlet are free.
- Make sure that the intake side is always free of dirt and loose objects.
- Do not place the device on a flammable surface.
- Only use original spare parts, otherwise no functional and safety-compliant operation is guaranteed.
- Allow the device to cool down before transport and/or maintenance.
- Do not use this unit near bathtubs, shower trays, swimming pools or other vessels that contain water. There is a risk of electric shock!
- Do not use this device again if it has been dropped or shows visible signs of damage.
- Do not insert rechargeable batteries into the remote control.
- Use the CR 2025 button battery type.
- Never charge batteries that cannot be recharged.
- Different battery types as well as new and used batteries may not be used together.
- Place the batteries in the battery compartment according to the correct polarity.
- Remove discharged batteries from the device. Batteries contain environmentally hazardous substances. Dispose of the batteries in accordance with national legislation (see chapter Environmentally friendly disposal).
- Remove the batteries from the remote control if you have not been using the device for an extended period of time.
- Never close the supply terminals in the battery compartment briefly!
- Do not swallow batteries! If a battery is swallowed, it can cause severe internal burns/burns within 2 hours! The burns can lead to death!
- If you think a battery has been swallowed or otherwise entered the body, see a doctor right away!
- Keep new and used batteries away from children, as well as an open battery compartment.
- If the battery compartment does not close securely, do not use the device via the remote control.
- The heater must not be placed directly under a wall socket.
- To avoid overheating, the heater must not be covered.
- **CAUTION!** Some parts of this product can get very hot and cause burns. Special care should be taken if children and vulnerable persons are present.
- **CAUTION!** To avoid the risk of accidental resetting of the thermal circuit breaker, this device must not be powered by an external switchgear, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.
- Read all instructions carefully before use.
- Make sure that the voltage specified on the device's nameplate matches.
- Keep the device and cable away from heat sources, sharp objects, or other things that could cause damage.
- Make sure the device is turned off before connecting it to the mains.
- Turn off the device and unplug it when not in use before cleaning it or performing other

maintenance.

- To unplug the device, turn it off and then unplug it from the wall outlet. Do not unplug the cable to unplug it.
- Do not operate the device in areas where gasoline, paint or other flammable liquids are used or stored.
- Use indoors only.
- In order to prevent a possible fire, the air inlets and outlets must not be blocked in any way.
- Do not touch the hot surfaces.
- Do not insert any foreign objects into the ventilation or exhaust air vents and do not allow them to penetrate, as this can lead to an electric shock, fire or damage to the device.
- Always make sure your hands are dry before pressing or adjusting a switch on the device or touching the plug and outlet.
- Do not leave the device unattended when it is in operation.
- The most common cause of overheating is deposits of dust or fluff in the device. Ensure that these deposits are removed regularly by unplugging the device and vacuuming the vents and grilles.
- Do not place the heater on carpets and do not lay the cable under carpets. Lay the cable away from traffic areas so you can't stumble over it.
- Store the heater in a cool, dry place when not in use and do not store it until it has cooled.
- Do not use the device to dry clothes.
- Do not immerse the device in liquids and do not let liquids run into the interior of the device, as this can lead to an electric shock.
- Do not use the device on a wet surface or where it can fall down or be pushed into the water.
- Do not reach for a device that has fallen into the water. Turn off the power supply and immediately unplug the power plug.
- Use the device only as described in this guide. Any other use is not recommended by the manufacturer and may cause fire, electric shock or injury.
- Do not use the device on a window, as rain can cause an electric shock.
- Do not store the device in a box or enclosed space until it has cooled down sufficiently.
- Do not use this device as a heater for animals and plants.

Intended use

The device is only suitable for well-insulated rooms or for occasional use. Use the device exclusively for heating enclosed spaces, in compliance with the technical data. The intended use includes the heating of:

- Flats
- Storage rooms
- Business premises
- Construction site rooms
- Containers
- Stacking

Foreseeable misuse

- Do not place the device on wet or flooded surfaces.
- Do not place objects, such as clothing, on the device.
- Do not use the device near gasoline, solvents, paints or other highly flammable fumes or in rooms where they are stored.
- Do not use the device outdoors.
- Do not use the device to heat vehicles.
- The device must not be used near swimming pools.
- Do not use the device in the immediate vicinity of sinks, bathtubs or other containers that contain water.
- This heater must not be used in wet rooms.
- Never submerge the device in water.
- Do not heat rooms with less than 4 m³ volume. There is a risk of overheating!
- This heater must not be used in wet rooms.
- Any use other than the intended use shall be deemed to be a reasonably foreseeable misuse.
- Unauthorized structural changes such as additions or conversions to the device are prohibited.

Personnel qualification

People using this device must:

- be aware of the dangers of working with electrical appliances in a humid environment.
- have read and understood the operating instructions, in particular the chapter on safety.

Maintenance activities that require the opening of the housing may only be carried out by electricians or by AREBOS.

2 Scope of delivery and information

Scope of delivery

• 1 x Convector / 1x Remote Control / 2 x Stand / 6 x Screw (for Stand) / 1 x Manual



No.	Designation
1	Handle
2	Air outlet
3	Stand with transport castors
4	Remote control
5	Power Cord Mount
6	On/off switch
7	Control panel
8	Display

Information about the device

- The device is used to generate warm air for indoor use.
- The device generates heat via an electric heating element.
- The air around the heating element is heated. The heated air rises through the air outlet upwards and to the sides and thus enters the room.
- The device has an integrated temperature sensor that regulates the heating level depending on the current and the desired room temperature.
- From the control panel, you can set a target temperature value between 15 °C and 35 °C.
- The device is operated via the control panel on the device or via the supplied infrared remote control.
- The device can be conveniently positioned in the room via the feet with integrated castors.

3 Installation and commissioning

WARNING! Make sure you are sufficiently distanced from walls, fixtures or other equipment. The distance must be at least 1 m from the front and side walls of the appliance in order to eliminate the risk of fire.

Unpack the device

- Remove the device and all accessories from the package. Check that the device has no signs of damage.
- Completely remove the packaging from the device.
- Unwind the power cord completely. Make sure that the power cord is not damaged and do not damage it when unwinding.
- Choose a fixed, flat and non-combustible location.
- Plug the power plug into a suitable 220 240V~50/60Hz outlet and make sure the power button is set to "OFF".

Assembly

WARNING! risk of injury due to incorrect installation due to electrical voltage! There may be local or national regulations for assembly. We recommend that you have the assembly carried out by an electrician.

WARNING! Fire hazard due to incorrect installation! There is a risk of fire if the required minimum distances are not observed. Pay full attention to the content in the chapter Assembly and commissioning as well as the technical data in the chapter Technical data.

Mounting feet with castors

WARNING! Make sure that the 2 feet are mounted before using the heater to ensure a sufficient distance to the stand surface.

- Put the device on its side.
- Screw the two feet (3) with 3 screws each.
- Check the feet (3) for a firm fit.
- Place the device upright and stable.



Commissioning

Info: Odours formation can occur during the first commissioning or after a long period of non-use. When setting up the device, observe the minimum distances to walls and objects according to the chapter Technical data.

- Before recommissioning the device, check the condition of the power cord. If you have any doubts about its perfect condition, call customer service.
- Place the device upright and stable.
- Avoid tripping points when laying the power cable or other electrical cables, especially when placing the device in the middle of the room. Use cable bridges.
- Ensure that cable extensions are fully rolled out or unrolled.
- Make sure that curtains or other objects do not hinder the flow of air.
- Do not place the device directly under a wall outlet.
- Make sure that the device cannot come into contact with moisture or water.

Insert batteries into remote control

Warning! before electric voltage Do not touch the battery compartment with damp or wet hands.

Hint! Do not run the device with rechargeable batteries!

Please note the technical data during commissioning.

- Squeeze the latch on the side of the battery compartment and pull the battery compartment out of the remote control.
- Insert a CR 2025 battery into the battery compartment and slide the battery compartment back into the remote control.
 - Be sure to place the batteries in the battery compartment according to the correct polarity.
- If you do not use it for a long time, remove the battery.

To avoid pollution, take out the used battery and dispose of it safely and properly.

Connect the power cord


- Plug the power plug into a properly secured power outlet.
- Make sure that the power cord is routed behind the device. Never run the power cord in front of the device!


4 Service

- Remove the heater and spare parts from the box and place it on a solid, flat floor or work surface.
- Before plugging the plug into the outlet, make sure that the power supply in your area matches the one indicated on the device's nameplate.
- Set the main button to Off. Plug the power cord into a 220-240V~AC outlet and set the main switch to "on".
- Turn on the device by pressing the main on/off switch. , the device displays the current room temperature.

• Avoid open doors and windows.

ControlsRemote control





All settings of the device can be made via the included remote control.

No.	Designation	Meaning	
9	Symbol	Low heating level activated (1200 W)	
	low heating level		
10	Symbol	high heating level activated (2000 W)	
	high heating level		
11	Symbol	Lights up when the desired or current room temperature is	
	Temperature	displayed in the segment display	
12	Symbol	Flashes when timer is enabled lights up during timer	
	Timer	programming	
13	Display	Lights up during temperature setting or timer programming	
	SET		
14	Кеу	Set the desired room temperature (15 °C to 35 °C) or number	
	Reduce value	of hours timer (1 to 24 h)	
15	Кеу	Timer programming temperature setting	
	FASHION		
16	Кеу	Set the desired room temperature (15 °C to 35 °C) or number	
	Increase value	of hours timer (1 to 24 h)	
17	Кеу	Turn on low heating level Turn on high heating level Put	
	Power	device into standby mode	
18	Segment display	Display of the current room temperature during operation	
		Display of the desired room temperature during the	
		temperature setting Display of the number of hours during	
		timer programming	

Warning! Fire hazard due to cover and incorrect positioning of the device! There is a risk of fire if you cover the device or position it incorrectly. Never cover the device during operation and position it at a sufficient distance from walls and objects (according to chapter Technical Data).

Turn on the device

After you have set up the device ready for operation as described in the chapter Assembly and Commissioning, you can switch it on.

- Set the power button (6) to position I. An acoustic signal sounds. The device is now in standby mode. The current room temperature is displayed in the segment display (18).
- Press the Power button (17).
 The device starts in the heating stage low heating level.
 The low heating level (9) icon is lit.

Info: The device stores the set room temperature in standby mode.

Setting the heating level

You can set the following heating levels:

- Low heating level (heating capacity 1200 W)
- high heating level (heating capacity 2000 W)
- Press the Power button (17) to set low heating. The low heating level (9) icon appears.
- Press the Power (17) button again to set the high heating level.
 The high heating level icon (10) is displayed in addition to the low heating level icon (9).

Set the desired room temperature

The room temperature determined by the temperature sensor is expressed in of the segment display (18). You can at any time use the Set the desired room temperature.

- Press the MODE (15) button repeatedly until the Temperature (11) icon flashes. The desired room temperature is displayed.
- Press the Increase Value (16) or Decrease Value (14) buttons to set the desired room temperature. The setting range is between 15 °C and 35 °C in 1° steps.
 The desired room temperature is stored and displayed for about 5 seconds in the segment display (18), after which the current room temperature is displayed again.

Info: The desired room temperature should be higher than the current room temperature.

Set timer

The timer works as follows:

- automatic switching on according to the preset number of hours
- automatic switch-off after a preset number of hours

The number of hours can be between 1 and 24 hours and in 1-hour steps.

Hint! The device must not be operated unattended in a freely accessible room when the timer is active.

Automatic power on

The device is turned on. The device is in standby mode.

- Press the MODE button (15).
 - The Timer (12) icon flashes.
- Use the Increase Value (16) or Decrease Value (14) buttons to select the desired number of hours.

The number of hours is displayed flashing for about 5 seconds in the segment display (18). The time until automatic switching on is saved. The Timer (12) icon flashes.

Automatic power off

The device is turned on.

The device heats in the set heating level.

- Press the MODE button (15).
- Use the Increase Value (16) or Decrease Value (14) buttons to select the desired number of hours.

If you select the number of hours 0, the timer is switched off.

The number of hours is displayed flashing for about 5 seconds in the segment display (18). The time until automatic shutdown is saved.

The Timer (12) icon flashes.

Notes on automatic power off:

- Manually turning off the device disables automatic power off.
- If you select the number of hours 0, the timer is switched off.

Decommissioning

Warning! from electrical voltage!

Do not touch the power plug with damp or wet hands.

- Turn off the device by setting the on/off switch (6) to position 0.
- Unplug the power cord from the power outlet by touching it on the power plug.
- Allow the device to cool down sufficiently.
- Clean the device according to the chapter Maintenance.
- Store the device according to the chapter Storage.

5 Errors and malfunctions

Warning! from electrical voltage! Activities that require the opening of the device may only be carried out by authorized specialist companies or by AREBOS.

The device was tested several times during production for proper functioning. Should malfunctions nevertheless occur, check the device in the following list.

The device does not start:

- Check the power connection.
- Check the power cord and power plug for damage. If you notice damage, do not try to get the device back up and running.
- If the mains connection line of this device is damaged, it must be replaced by the manufacturer or his customer service or a similarly qualified person to avoid hazards.
- Check the on-site network protection.
- Check the room temperature. The room thermostat may have switched off because the

desired room temperature has been reached.

- The room thermostat may be defective. Have a defective room thermostat replaced by a specialist electrical company.
- Check whether the overheat protection has triggered (see chapter Introduction and Safety Instructions).
- Wait 10 minutes before restarting the device. If the device does not start, have an electrical inspection carried out by a specialist company or by AREBOS.

The device is turned on, but it does not heat:

- Check the room temperature. The room thermostat may have switched off because the desired room temperature has been reached.
- Check whether the overheating protection has triggered (see chapter Introduction and Safety Instructions).
- The heating resistance may have burned through. Have a defective heating resistor replaced by an electrician.
- The room thermostat may be defective. Have a defective room thermostat replaced by a specialist electrical company.

The device does not respond to the infrared remote control:

- • Check if the distance from remote control to device is too large and reduce the distance if necessary.
- Make sure there are no obstacles, such as furniture or walls, between the device and the remote control. Pay attention to visual contact between the device and the remote control.
- Check the state of charge of the batteries and replace them if necessary.
- Check the batteries for the correct polarity if the batteries have just been replaced.

Hint! Wait at least 3 minutes after all maintenance and repair work. Only then turn the device back on.

Your device is not working properly after the checks?

Contact customer service. If necessary, take the device to an authorized electrician or to AREBOS for repair.

6 Maintenance and cleaning

Activities before maintenance begins

Warning! from electrical voltage! Do not touch the power plug with damp or wet hands.

- Turn off the device.
- Unplug the power cord from the power outlet by touching it on the power plug.
- Allow the device to cool completely.

Warning! from electrical voltage! Activities that require the opening of the device may only be carried out by authorized specialist companies or by AREBOS.

Cleaning the housing

Warning! from electrical voltage! Never submerge the device under water! Clean the case with a damp, soft, lint-free cloth. Make sure that no moisture penetrates into the housing. Make sure that no moisture can come into contact with electrical components. Do not use aggressive detergents, such as cleaning sprays, solvents, alcohol-containing cleaners, or abrasives to moisten the cloth.

Wipe the housing dry after cleaning.

7 Transport and storage

Hint! If you store or transport the device improperly, the device may be damaged. Observe the information on the transport and storage of the device.

Transport

The device is equipped with transport rollers for easier transport. The device is equipped with a handle for easier transport. Please note the following **before** each transport:

- Turn off the device.
- Unplug the power cord from the power outlet by touching it on the power plug.
- Do not use the power cord as a pull cord.
- Allow the device to cool down sufficiently.

Storage

Observe the following instructions **before** each storage:

- Turn off the device.
- Unplug the power cord from the power outlet by touching it on the power plug.
- Allow the device to cool down sufficiently.

When not using the device, comply with the following storage conditions:

- dry and protected from frost and heat
- in an upright position in a place protected from dust and direct sunlight
- if necessary, protected from penetrating dust with a cover
- no other devices or objects on the device to avoid damage to the device
- Remove batteries from the remote control

8 Specifications

Parameter	Value
Model	AR-HE MKV2000B
Heat output	1200 - 2000 W
Mains connection	220-240 V ~/ 50-60 Hz
Power consumption, max.	2000 W
Workspace	-9 °C to 35 °C
Adjustment range	15 °C to 35 °C
Cable length	1.2 m
Plug type	Schuko plug CEE 7/7
Class	1
Dimensions (depth x width x height)	260 x 640 x 660 mm
Minimum distance to walls and objects	
above:	100 cm
behind:	100 cm
lateral:	100 cm
in front:	100 cm
Weight	5 kg
Batteries Remote Control	Type CR 2025

In the course of product improvements, we reserve the right to make technical and visual changes to the article.

Required information on electric local space heaters

Parameter	Value / Specification
Model	AR-HE MKV2000B
Heat	
Nominal heat output Pnom	2 kW
Minimum heat output (guideline) ^{P min}	1 kW
Maximum continuous heat output Pmax,c	2 kW
Auxiliary power consumption	
At nominal heat output elmax	NA
With minimum heat output elmin	NA
In standby mode elsb	0,00162
Type of control of the heat supply	
Manual control of the heat supply with integrated thermostat	No
Manual control of the heat supply with feedback of the room	No
and/or outside temperature	NL
Electronic control of the heat supply with feedback of the	No
room and/or outside temperature	NI -
Heat dissipation with blower support	No
Type of heat output/room temperature control	
single-stage heat output, no room temperature control	No
two or more manually adjustable levels, no room temperature control	No
Room temperature control with mechanical thermostat	No
with electronic room temperature control	No
Electronic room temperature control and time of day control	Yes
Electronic room temperature control and weekday control	No
Other control options	
Room temperature control with presence detection	No
Room temperature control with detection of open windows	No
with remote control option	Yes
with adaptive control of the heating start	No
with uptime limitation	No
with black ball sensor	No
Contact details	Canbolat Vertriebs GmbH,
	Gneisenaustraße 10-11,
	97074 Würzburg, Germany

NA: Not applicable

9 Environmentally friendly disposal

Warning! from the risk of suffocation! Packaging material is dangerous for children. Never let children play with packaging material.

9.1 Disposal and packaging

• The packaging of your device is made of materials necessary to guarantee effective protection during transport. These materials are fully recyclable and thus reduce the environmental impact. Dispose of the packaging in a bin for recyclable materials.

9.2 Disposal of waste equipment

• Waste equipment must be disposed of in accordance with the guidelines and regulations of local waste disposal. Contact your local administration via the address of the nearest recycling centre and deliver your device there.



The symbol of the crossed-out waste bin on an OLD electrical or electronic equipment states that it must not be disposed of in household waste at the end of its service life. Collection points for WASTE electrical and electronic equipment are available in your area for free returns. You can obtain the addresses from your city or local government. You can inform yourself on our website <u>www.arebos.de</u> about other return options created by us.

The separate collection of WEEE is intended to prevent reuse, recycling or other forms of recovery of WEEE, as well as the negative consequences of disposal on the environment and human health.

Note on battery disposal

The symbol of the crossed-out trash can on batteries or accumulators states that they must not be disposed of in household waste at the end of their service life. If batteries or accumulators contain mercury (Hg), cadmium (Cd) or lead (Pb), you will find the respective chemical symbol below the symbol of the crossed-out trash can. You are legally obliged to return old batteries and accumulators after use. You can do this free of charge at the retail store or at another collection point in your area. Addresses of suitable collection points can be obtained from your city or local government.

Our customer service number: Tel. +44 (0) 20 8068 5604 fax: +49 (0) 931 4523 2799 / e-mail: <u>info@arebos.de</u>

Office address: Canbolat Vertriebs GmbH • Gneisenaustraße 10-11 • 97074 Würzburg

Return address can be found in the imprint: https://www.arebos.de/impressum/

Sales tax identification number: DE 263752326 Court of commercial registration is Würzburg, HRB 10082 WEEE-Reg. No. DE 61617071

EU Declaration of Conformity

CE

We, the

Canbolat Vertriebsgesellschaft mbH

Gneisenaustrasse 10-11 97074 Würzburg, Germany

declare, under sole responsibility, that the following product:

Brand

AREBOS

Product

Convector 2000W

Product Model Article AR-HE MKV2000B 4252023107396

has been developed, designed and2014/30/EUmanufactured in accordance with2014/35/EUthe requirements of European2011/65/EU / 2015/863/EUdirectives:2009/125/EC

The subject matter of the declaration described above is in accordance with the relevant harmonisation legislation of the European Union.

The assessment shall be based on the following **harmonised standards** applied: EN 55014-1:2021 EN 55014-2:2021 EN 61000-3-2:2019+A1:2021 EN 61000-3-3:2013+A1:2019 EN 60335-2-30:2009+A11:2012 EN 60335-1:2012+A11:2014+A13:2017+A1:2019+A14:2019+A2:2019 EN 62233:2008

Other applied technical standards and specifications:

Regulation (EU) 2015/1188

Place and date of issue:

Würzburg, 12.07.2022

Signature:

Dipl.-Inform. (Univ.) Korhan Canbolat, Managing Director

If the device is modified without our consent, this declaration of conformity loses its validity.