

AREBOS

3D Table Fan 55W

AR-HE-LZTV55W



Please follow all security measures in this user's manual to ensure a secure use.



Thank you for trusting in AREBOS.

List of contents

1. Introduction and safety instructions	3
1.1 Introduction.....	3
1.2 Explanation of the symbols	3
1.3 General safety instructions.....	4
1.4 Specific safety instructions	5
2. Use	6
2.1 Control panel	6
2.2 Select blower level.....	6
2.3 Mode button	6
2.4 Set Timer	7
2.5 Tilt angle	7
2.6 Oscillation	7
2.7 Turning off	8
2.8 Remote control.....	8
3. Technical data	9
4. Cleaning and maintenance.....	9
5. Environmentally friendly disposal.....	10
5.1 Disposal and packaging	10
5.2 Disposal of old equipment.....	10
EU Declaration of Conformity	11

Thank you for purchasing our product. Please read the operating instructions carefully before using the product for the first time. If you give the product to a third party, this manual must be handed over with it. Protect yourself and others by observing all safety information, warnings and precautions. Failure to follow the instructions may result in injury and/or damage to the product or property. Keep the instruction manual for future reference. The drawings in this manual may not match the physical objects. Please refer to the physical objects.

1. Introduction and safety instructions

1.1 Introduction

- These operating instructions are intended to familiarise you with the installation, use and maintenance of the appliance. To install the unit safely and correctly, please read the operating instructions **before** you start.
- Check the unit for any damage that may have occurred during transport. Immediately report any damage to the carrier by which the product was delivered.

1.2 Explanation of the symbols



By means of a CE marking, it can be recognized that a product complies with the legal provisions of European legal standards and therefore may be traded within the European Community.




Warning! Read the safety instructions carefully. Failure to follow the safety precautions could result in serious injury or damage. Keep the operating instructions in a safe place.



Be careful when using this product.



Warning of electrical voltage!



Note: Pull out mains plug!



This product must **not** be disposed of with household waste!




Protected housing (protection class II)!



Warning! Do not put fingers and other limbs in the fan housing!

1.3 General safety instructions

- Your safety is of the most importance to us. Please make sure that you read this instruction booklet **before** attempting to install and use the appliance. If you are unsure of any of the information contained in this booklet, please contact the Retailer where you purchased your unit.
-  **WARNING:** Read all safety warnings and instructions. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury. Save all warnings and instructions for future reference.
- **DO NOT** use the product until you read the instruction manual.
- Ensure that these notes and that the whole of this instruction book are thoroughly read and understood before installation or operation of the hob.
- The instructions are provided in the interest of your safety.
- Read the instructions carefully. It contains important instructions for the use, safety and maintenance of the device. It should be stored carefully and, if necessary, passed on to subsequent users.
- The device may only be used for the intended purpose, in accordance with these instructions for use.
- This device may be used by children 8 years old and over, and by persons with reduced physical, sensory or mental abilities, or lack of experience and knowledge, if they have been supervised or instructed in the safe device and understand the hazards arising therefrom.
- Keep the device and its supply out of the reach of children under 8 years of age.
- Children are not allowed to play with the device.
- Cleaning and user maintenance must not be performed by children without supervision.
- Turn off the device before disconnecting it from the power supply.
- If the power cord of this equipment is damaged, it must be replaced by the manufacturer's centralized service department or a similarly qualified person. Improper repairs can cause significant risks for the user.
- Before commissioning, check the device and its connecting cable and accessories for damage.
- Do not use the device if it has visible damage.
- Before connecting to the power supply, make sure that the voltage indicated on the rating plate matches the voltage of your power outlet. Use only sockets with protective contact.
- Do not crush the connecting cable, do not pull it over sharp edges or hot surfaces. Do not use the connecting cable for carrying.
- If the power cord of this equipment is damaged, it must be replaced by the manufacturer or a similarly qualified person to avoid hazards.
- Disconnect the mains plug of the device after each use, in case of faults during operation and before every cleaning of the device.
- Never disconnect the plug from the power cord or with wet hands.

- Never use the device after a malfunction, e.g. if the device has fallen into the water or has fallen or been damaged in any other way.
- The manufacturer assumes no responsibility for incorrect use, which results from non-observance of the instructions for use.
- Modifications of the product will affect product safety.
- All modifications and repairs to the device or accessories may only be carried out by the manufacturer or persons expressly authorized by the manufacturer.
- Make sure that the product is operated from a power outlet that is easily accessible so you can quickly unplug the unit in case of an emergency.
- If possible, do not use extension cords. If this is unavoidable, use only GS-approved, splash-proof, simple extension cords (not multi-outlet) designed to handle the power consumption of the unit.
- To avoid a dangerous electric shock, never splash or pour water on the device.


1.4 Specific safety instructions

- The device is intended for household or similar use only. It may not be used for commercial purposes!
- Please use the product only in its intended manner.
- Any other use may result in damage to the product or the environment of the product.
- The device is only suitable for indoor use.
- Make sure that the device has good stability during operation and that the power cable does not become a hindrance or tripping hazard.
- The device must be placed on a firm and dry surface during use, such as to stand at a table. Do not place the fan on an unstable or textile-covered surface. Make sure that the device is stable so that nobody can knock it over. Around the device, a space of about 50 cm should remain free.
- Never use the ventilator near a table edge, making sure it is out of the reach of children and pets to prevent the unit from being pulled down and being damaged.
- Do not let the power cord hang over the edges of the table so that it cannot be pulled down. Be careful not to cover it with hot surfaces, such as a stove or a radiator or comes into contact with the device itself. Always unwind the cable completely before plugging in the mains plug.
- Keep the device away from hot gas, hot ovens or other heat-emitting devices or heat sources. Never use the appliance on a wet or hot surface. Do not place the device near humidity, heat and open flames. Keep the device away from moving parts or devices.
- Do not use the device in rooms containing explosive or flammable substances or liquids. Do not use the fan in rooms with high humidity, at room temperatures over 40 ° C or in dusty rooms.
- Do not leave loose, small or light objects near the unit. These can be sucked into the interior of the device.
- The device must not be used in the bathroom.
- Do not allow the cool air to blow you directly and do not let the air in the room get too cold. Malaise and health damage can be caused.
- Do not place plants or animals directly in the cool air stream. Animals and plants can suffer from the cool air flow.
- Never block the air intake or exhaust. Do not operate the device covered.
- Only operate with completely unrolled cable!
- Never use the device without a protective grille.
- Keep the device away from TV and radio equipment to avoid electromagnetic interference.
- Do not touch the device or the control panel with wet or damp hands.


2. Use

- Place the fan on a flat, even surface.
- Connect the fan to the power supply.
- Press the ON/OFF button on the remote control or control panel to turn on the fan.

2.1 Control panel



2.2 Select blower level



- Press the +/- button to switch to the desired fan speed (1-4). The LED lamp of the corresponding stage lights up.

2.3 Mode button



- Press the mode button and you can choose between sleep mode (gentle ventilation) and "storm" mode (highest level).

2.4 Set Timer

4h

2h

1h




- Press the timer button to set the timer in hours (1 → 2 → 3 → 4 → 5 → 6 → 7 → off). The LEDs of the corresponding number of hours light up.

Timer	1 hr-LED	2 hr-LED	4 hr-LED
1 hour	ON	OFF	OFF
2 hours	OFF	ON	OFF
3 hours	ON	ON	OFF
4 hours	OFF	OFF	ON
5 hours	ON	OFF	ON
6 hours	OFF	ON	ON
7 hours	ON	ON	ON
OFF	OFF	OFF	OFF

2.5 Tilt angle

- Press the tilt angle button to tilt the fan head. The fan head moves from top to bottom and back again until you stop it by pressing the button again. He then stops in the stopped position.



2.6 Oscillation

- Press the oscillation button on the remote control or control panel to swivel the fan head. The fan head moves from right to left and back again until you stop it by pressing the button again. He then stops in the stopped position.



2.7 Turning off

- Press the ON/OFF button on the remote control or control panel to put the fan into standby mode. Disconnect the power plug from the power supply to turn off the fan.



2.8 Remote control



- The same symbols and symbol descriptions apply to the remote control.

3. Technical data

Model	AR-HE-LTV55W
Input	55 W
Voltage	220-240 V / 50-60 Hz
Dimension (L x W x H)	11.22 x 11.22 x 15.12 in (285 x 285 x 384 mm)
Diameter Head	8.9 in (226 mm)
Air flow	7.5 m/s
Number of fan steps	4
Timer	1 -7 hours
Number of fan blades	5
Height adjustable	Yes
Oscillation	Right/left: 65° sowie up/down: 85°
Connector	VED double round plug
Material cable	Cooper
Cable length	5.91 ft (1.8 m)
For room sizes up to	15 m ²
Max. range remote control	3 m
Sound value	≤ 55 dB(A)
Protection class	II
Colour	White
Weight	4.63 lbs (2.1 kg)

4. Cleaning and maintenance

- Clean the fan regularly.
- Never immerse the cable and the device in water or rinse under running water.
- **Warning:** Always disconnect the device from the power before moving or cleaning it.
- Disconnect power and wait for the fan to stop before cleaning.
- Clean the guard with a vacuum cleaner of dust and other debris.
- Use a damp cloth to clean the surface of the device.
- The following agents should not be used for cleaning: petrol, paint thinner or other chemicals.
- Allow the fan to dry completely before using it again.
- Leave the fan completely assembled for storage.
- Keep the fan in a cool, dry and safe place away from children and animals when not using the fan for a long time. The device must not be stored in a hot location or under direct sunlight.
- At best, store the fan in its original packaging.

5. Environmentally friendly disposal

5.1 Disposal and packaging

- The packaging of your unit consists of materials that are necessary to guarantee effective protection during transport. These materials are fully recyclable and therefore reduce the environmental impact. Dispose of the packaging in a bin for recyclable materials.

5.2 Disposal of old equipment

- Old appliances must be disposed of in accordance with the guidelines and regulations of the local waste disposal authority. Check with your local administration for the address of the nearest recycling centre and deliver your appliance there.



The symbol of the crossed-out dustbin on a Waste electrical or electronic equipment indicates that it must not be disposed of with household waste at the end of its life. Collection points for waste electrical and electronic equipment are available free of charge in your area. You can obtain the addresses from your city or local government. You can find out about other return options created by us on our website www.arebos.de.



The separate collection of Waste electrical or electronic equipment is intended to enable the reuse, recycling or other forms of recovery of Waste electrical or electronic equipment and to avoid the negative consequences of disposal on the environment and human health.

Notes on battery disposal

The symbol of the crossed-out dustbin on batteries or accumulators indicates that they must not be disposed of with household waste at the end of their service life. If batteries or accumulators contain mercury (Hg), cadmium (Cd) or lead (Pb), you will find the respective chemical symbol below the symbol of the crossed-out trash can. You are legally obliged to return old batteries and accumulators after use. You can do this free of charge in a retail store or at another collection point near you. Addresses of suitable collection points can be obtained from your city or local government.

Our customer service number: Tel. +44 (0) 208 068 5604

Fax: +49 (0) 931 4523 2799 / E-Mail: info@arebos.de

Canbolat Vertriebs GmbH • Gneisenastraße 10-11 • 97074 Würzburg

EU Declaration of Conformity

We, the

Canbolat Vertriebs GmbH, Gneisenaustraße 10-11, 97074 Würzburg, Germany

Hereby declare that the devices described in the following comply with the relevant, fundamental safety and health requirements of the EU directives due to their design and construction as well as in the versions marketed by us.

Product name: AREBOS 3D Table Fan 55W

Article number: 4260627421473

Model number: AR-HE-LZTV55W

If the device is modified without our consent, this declaration of conformity loses its validity.

Directives

This device complies with the following EU/EC directives:

2014/30/ EU EMC Directive

2014/35/ EU Low Voltage Directive

2009/125/ EC Ecodesign Directive

Date/Signature Manufacturer/Location:

Würzburg, 01.10.2021



Signature:

Dipl.-Inform. (Univ.) Korhan Canbolat, Managing Director

Representative of this User Manual/Technical Data:

Dipl.-Inform. (Univ.) Korhan Canbolat, Managing Director

Office address:

Canbolat Vertriebs GmbH

Gneisenaustraße 10-11

97074 Würzburg

You can find the return address in the imprint: <https://www.arebos.de/impressum/>

VAT identification number: DE 263752326

The court of entry in the commercial register is Würzburg, HRB 10082

WEEE-Reg.-Nr. DE 61617071